

Levitronix® Standard Article List and Order Information Bearingless Fan BFS-i10, Accessories and Spare Parts

Article Name (and Description)	Part No.	Article Category	Note
Standard System Configurations			
Bearingless Fan BFS-i10.1 (ATEX/IECEX, 5 m + 0.2 m PVC motor cable with TE connectors for power and PLC)	100-10207	BFS-(i)	
Bearingless Fan BFS-i10.1-30 (ATEX/IECEX, 3 m + 0.2 m PVC motor cable with TE connectors for power and PLC)	100-10208	BFS-(i)	
Accessories			
Adaptor Cable Power ICP-6.1-03 (0.3 m, open wires with TE connector)	190-10499	Accessories BFS	Connection of fan cable to DC power supply.
Adaptor Cable Signals ICS-5.1-03 (0.3 m, open wires with TE connector) Adaptor Cable Signals ICS-5.1-15 (1.5 m, open wires with TE connector)	190-10464 190-10491	Accessories BFS	Connection of fan cable to PLC signals and RS485 fieldbus.
Interface Panel FIP-2.1 (Connect up to 4 fans, common RS485 bus and power supply, direct connection of LUI-B.1 or USB-RS485 adaptor, push-in connectors for PLC)	100-91659	Accessories BFS	Easy wiring of PLC signals for up to four BFS-i10 fans.
User Panel LUI-B.1-06 (Handheld with firmware A8.00, IP65, 5 to 24 V supply)	100-30549	Accessories Pump Systems	Control of fan via handheld device with display and menu buttons.
USB-RS485 Adaptor YN-485I-TR (Isolated USB to RS485 adaptor with termination resistor, 2 m cable with PVC jacket, USB to screw type connector)	100-30392	Accessories IPS	Control or service via USB port of a PC with Levitronix® Service Software.
IP Adaptor Cable Signal 6 Wires ICS-1.1-10 (1 m, PVC jacket, circular to circular connector) IP Adaptor Cable Signal 6 Wires ICS-1.1-30 (3 m, PVC jacket, circular to circular connector)	190-10344 190-10345	Accessories IPS	Connection of user panel (LUI-B.1) to interface panel (FIP-2.1).
IP Adaptor Cable Signal 6 Wires ICS-1.2-10 (1 m, PVC jacket, circular to screw type connector) IP Adaptor Cable Signal 6 Wires ICS-1.2-50 (5 m, PVC jacket, circular to screw type connector)	190-10440 190-10346	Accessories IPS	Connection of user panel (LUI-B.1) to adaptor cable (ICS-5.1) and 5 to 24 V supply.
IP Adaptor Cable Signal 6 Wires ICS-1.3-50 (5 m, PVC jacket, circular to screw type connector)	190-10389	Accessories IPS	Connection of interface panel (FIP-2.1) to USB adaptor (YN-485I-TR).
ATEX Cable Sealing System ACS-A.1 (Roxtec)	100-90292	Accessories Pump Systems	
Spare Parts			
--	--		