

Levitronix® Standard Article List and Order Information

Levitronix Pinch Valve Systeme LPVS-i, Sets, Accessories and Spare Parts

Article Name (and Description)	Part No.	Article Category	Note
LPVS-i Pinch Valve Systems			
Levitronix® Pinch Valve System LPVS-i100.1 (Up to 0.375"=3/8" Tubing)	100-30566	LPVS Pinch Valves	
Levitronix® Pinch Valve System LPVS-i200.1 (Up to 0.625"=5/8" Tubing)	100-30495	LPVS Pinch Valves	
Levitronix® Pinch Valve System LPVS-i400.1 (Up to 1" Tubing)	100-30496	LPVS Pinch Valves	
Levitronix® Pinch Valve System LPVS-i400P.1 (Up to 1.405" Tubing)	100-30562	LPVS Pinch Valves	Coming Soon
Levitronix® Pinch Valve System LPVS-i800.1 (Up to 1.5" Tubing)	100-30497	LPVS Pinch Valves	
Note 1: Tube inserts to be ordered as separate article.			
Accessories			
Pinch Valve Insert PVI-100.1	190-10556	Accessories LPVS	Inserts for LPVS-i100 pinch valves. See manual or technical brochure for details to inserts and their compatibility for various tubing types.
Pinch Valve Insert PVI-200.2	190-10513	Accessories LPVS	Inserts for LPVS-i200 pinch valves.
Pinch Valve Insert PVI-200.3	190-10514		
Pinch Valve Insert PVI-200.4	190-10515		
Pinch Valve Insert PVI-200.5	190-10543		
Pinch Valve Insert PVI-400.1	190-10516	Accessories LPVS	Inserts for LPVS-i400 pinch valves.
Pinch Valve Insert PVI-400.2	190-10517		
Pinch Valve Insert PVI-400P.1	190-10596	Accessories LPVS	Inserts for LPVS-i400P pinch valves.
Pinch Valve Insert PVI-400P.2	190-10597		
Pinch Valve Insert PVI-800.1	190-10518	Accessories LPVS	Inserts for LPVS-i800 pinch valves.
Pinch Valve Insert PVI-800.2	190-10519		
Panel Seal Set PSS-100.1 (FPM Flat Gasket and Mounting Screws for LPVS-i100)	190-10557	Accessories LPVS	For mounting and sealing the valve to a cabinet wall.
Panel Seal Set PSS-200.1 (FPM O-Ring and Mounting Screws for LPVS-i200)	190-10548		
Panel Seal Set PSS-400.1 (FPM O-Ring and Mounting Screws for LPVS-i400)	190-10549		
Panel Seal Set PSS-800.1 (FPM O-Ring and Mounting Screws for LPVS-i800)	190-10550		
Valve Base Mount VBM-100.1 (Stainless steel Mounting Plate for LPVS-i100)	190-10558	Accessories LPVS	For standalone operation, base or wall mounting.
Valve Base Mount VBM-200.1 (Stainless steel Mounting Plate for LPVS-i200)	190-10545		
Valve Base Mount VBM-400.1 (Stainless steel Mounting Plate for LPVS-i400)	190-10546		
Valve Base Mount VBM-800.1 (Stainless steel Mounting Plate for LPVS-i800)	190-10547		
Valve Base Mount VBM-100.2 (Stainless steel Mounting Plate for LPVS-i100)	190-10627	Accessories LPVS	For space saving base, cabinet or wall mounting.
Valve Base Mount VBM-200.2 (Stainless steel Mounting Plate for LPVS-i200)	190-10628		
Valve Base Mount VBM-400.2 (Stainless steel Mounting Plate for LPVS-i400)	190-10629		
Valve Base Mount VBM-800.2 (Stainless steel Mounting Plate for LPVS-i800)	190-10630		
User Panel LUI-B.1-05 (Display with Menu Buttons)	100-30527	Accessories LPVS	
Desktop AC/DC Power Supply GST160A24-R7B IC915 (24VDC/160W, Auto AC, Circ. Intercon.Connector)	100-40020	Accessories IPS	AC mains cable ACM-1.x for various countries to be ordered as separate article.
AC Mains Cable AMC-1.1 (2m, US, Canada)	190-10331	Accessories IPS	AC cable for desktop power supply.
AC Mains Cable AMC-1.2 (2.5m, GE, DK, NO, FI, BE, NL, SE, AT)	190-10332		
AC Mains Cable AMC-1.3 (2.5m, Japan)	190-10333		
AC Mains Cable AMC-1.4 (2.5m, Switzerland)	190-10334		
AC Mains Cable AMC-1.5 (2.5m, United Kingdom)	190-10335		
AC/DC Power Supply TIB 480-124 (24VDC/480W)	100-40030	Accessories LPVS	For multiple valves the same time. (9-24 valves depending on size)
IPS Split Cable ICY-2.1-02 (0.2m, PVC cables, PA Box, TPE Sealing, circ. Connectors)	190-10466	Accessories IPS	Splits pinch valve to power supply and user panel.
IPS Cable Signal 6 Wires ICS-1.1-10 (1m)	190-10344	Accessories IPS	Interconnect cable for user panel LUI-B.1
IPS Cable Signal 6 Wires ICS-1.1-30 (3m)	190-10345		
IPS Cable Signal 6 Wires ICS-1.3-50 (5m PVC, Circ. Connector to Screw Type Connect.)	190-10389	Accessories IPS	Interconnect cable from fieldbus of split cable to USB/RS485 adaptor.
IPS Cable Signal 8 Wires ICS-6.1-50 (5m PVC, Circular Straight Conn. to Open Wire)	190-10522	Accessories LPVS	For OEM connection of pinch valves.
IPS Cable Signal 8 Wires ICS-6.2-50 (5m PVC, Circular Rectangular Conn. to Open Wire)	190-10539	Accessories LPVS	For OEM connection of pinch valves.
IPS Cable Signal 8 Wires ICS-6.3-50 (5m PVC, Circular to Circular Connector)	190-10542	Accessories LPVS	For connecting pinch valve to ICY-2.1 split cable.
USB-RS485 YN-485I-TR (USB to RS485 Adaptor, Isolated, Cable with Termination Resistance)	100-30392	Accessories IPS	For connecting pinch valve to PC with Service Software.
Spare Parts			
--			