Levitronix® Standard Article List and Order Information
LEVIFLOW® Flowmeter LFS Series
Sets, Accessories and Spare Parts

Article Name (and Description)	Part No.	Note
LeviFlow Sets - Flowsensor with Converter LFC-1C		
LeviFlow Set LFS-008-Z + LFC-1C-F4 Sensor LFS-008-Z (0 - 0.8 lpm, Z-shape, calibration included) Converter LFC-1C-F4 (24VDC, 2 Digital Outputs, 1 Digital Input, RS485) **LeviFlow Set LFS-008-U + LFC-1C-F4** (U-shape) *Note: Converter contains calibrated sensor specific parameters* *Note: Extension cables to be ordered as seperate article.*	**100-90625** **100-90626**	
LeviFlow Set LFS-04-Z + LFC-1C Sensor LFS-04-Z (0 - 4 lpm, Z-shape, calibration included) Converter LFC-1C (24VDC, 2 Digital Outputs, 1 Digital Input, RS485) **LeviFlow Set LFS-04-U + LFC-1C** (U-shape) *Note: Converter contains calibrated sensor specific parameters* *Note: Extension cables to be ordered as seperate article.*	**100-90604** **100-90605**	
LeviFlow Set LFS-04-Z-T025 + LFC-1C Sensor LFS-04-Z-T025 (0 - 4 lpm, Z-shape, calibration included, 1/4" Fittings) Converter LFC-1C (24VDC, 2 Digital Outputs, 1 Digital Input, RS485) **LeviFlow Set LFS-04-U-T025 + LFC-1C** (U-shape) *Note: Converter contains calibrated sensor specific parameters* *Note: Extension cables to be ordered as seperate article.*	**100-90627** **100-90628**	
LeviFlow Set LFS-08-Z + LFC-1C Sensor LFS-08-Z (0 - 8 lpm, Z-shape, calibration included) Converter LFC-1C (24VDC, 2 Digital Outputs, 1 Digital Input, RS485) **LeviFlow Set LFS-08-U + LFC-1C** (U-shape) *Note: Converter contains calibrated sensor specific parameters* *Note: Extension cables to be ordered as seperate article.*	**100-90606** **100-90607**	
LeviFlow Set LFS-20-Z + LFC-1C Sensor LFS-20-Z (0 - 20 lpm, Z-shape, calibration included) Converter LFC-1C (24VDC, 2 Digital Outputs, 1 Digital Input, RS485) **LeviFlow Set LFS-20-U + LFC-1C** (U-shape) *Note: Converter contains calibrated sensor specific parameters* *Note: Extension cables to be ordered as seperate article.*	**100-90608** **100-90609**	
LeviFlow Set LFS-50-Z + LFC-1C Sensor LFS-50-Z (0 - 50 lpm, Z-shape, calibration included) Converter LFC-1C (24VDC, 2 Digital Outputs, 1 Digital Input, RS485) **LeviFlow Set LFS-50-U + LFC-1C** (U-shape) *Note: Converter contains calibrated sensor specific parameters* *Note: Extension cables to be ordered as seperate article.*	**100-90621** **100-90622**	
LeviFlow Set LFS-80-Z + LFC-1C Sensor LFS-80-Z (0 - 80 lpm, Z-shape, calibration included) Converter LFC-1C (24VDC, 2 Digital Outputs, 1 Digital Input, RS485) **LeviFlow Set LFS-80-U + LFC-1C** (U-shape) *Note: Converter contains calibrated sensor specific parameters* *Note: Extension cables to be ordered as seperate article.*	**100-90623** **100-90624**	
LeviFlow Articles for Configurations with Multichannel Converter LFC-6C		
LeviFlow Converter LFC-6C (24VDC, 6-Channel, RS485) *Note: Connector and Termination Box to be ordered as seperate article.*	**100-30315**	
LeviFlow Sensor LFS-04-Z (0 - 4 lpm, 0.5m FEP cable, Z-shape, connector cover, calibration incl.) **LeviFlow Sensor LFS-04-U** (U-shape)	**100-30304** **100-30305**	
LeviFlow Sensor LFS-04-Z-T025 (0 - 4 lpm, 0.5m FEP cable, Z-shape, connector cover, calibration incl., 1/4" Fittings) **LeviFlow Sensor LFS-04-U-T025** (U-shape)	**100-30321** **100-30322**	
LeviFlow Sensor LFS-08-Z (0 - 8 lpm, 0.5m FEP cable, Z-shape, connector cover, calibration incl.) **LeviFlow Sensor LFS-08-U** (U-shape)	**100-30306** **100-30307**	
LeviFlow Sensor LFS-20-Z (0 - 20 lpm, 0.5m FEP cable, Z-shape, connector cover, calibration incl.) **LeviFlow Sensor LFS-20-U** (U-shape)	**100-30308** **100-30309**	
LeviFlow Sensor LFS-50-Z (0 - 50 lpm, 0.5m FEP cable, Z-shape, connector cover, calibration incl.) **LeviFlow Sensor LFS-50-U** (U-shape)	**100-30310** **100-30311**	
LeviFlow Sensor LFS-80-Z (0 - 80 lpm, 0.5m FEP cable, Z-shape, connector cover, calibration incl.) **LeviFlow Sensor LFS-80-U** (U-shape)	**100-30312** **100-30313**	

Accessories		
Pair of LeviFlow Extension Cable LFE-A.1-10 (1m, PVC flameretardent, connector cover)	**190-10162**	
Pair of LeviFlow Extension Cable LFE-A.1-30 (3m, PVC flameretardent, connector cover)	**190-10163**	
Pair of LeviFlow Extension Cable LFE-A.1-60 (6m, PVC flameretardent, connector cover)	**190-10164**	
Pair of LeviFlow Extension Cable LFE-A.2-10 (1m, FEP, connector cover)	**190-10165**	
Pair of LeviFlow Extension Cable LFE-A.2-30 (3m, FEP, connector cover)	**190-10166**	
Pair of LeviFlow Extension Cable LFE-A.2-60 (6m, FEP, connector cover)	**190-10167**	
LeviFlow Connector for LFC-6C (for wiring)	**100-30316**	
LeviFlow Termination Box for LFC-6C (for termination of RS485)	**100-30317**	
Spare Parts		
LeviFlow Sensor LFS-008-Z (0-0.8 lpm, 0.5m FEP cable, Z-shape, connector cover, calibration incl., 1/4" Fittings) **LeviFlow Sensor LFS-008-U** (U-shape)	**100-30323** **100-30324**	
LeviFlow Sensor LFS-04-Z (0 - 4 lpm, 0.5m FEP cable, Z-shape, connector cover, calibration incl., 3/8" Fittings) **LeviFlow Sensor LFS-04-U** (U-shape)	**100-30304** **100-30305**	
LeviFlow Sensor LFS-04-Z-T025 (0 - 4 lpm, 0.5m FEP cable, Z-shape, connector cover, calibration incl., 1/4" Fittings) **LeviFlow Sensor LFS-04-U-T025** (U-shape)	**100-30321** **100-30322**	
LeviFlow Sensor LFS-08-Z (0 - 8 lpm, Z-sape) **LeviFlow Sensor LFS-08-U** (U-shape)	**100-30306** **100-30307**	
LeviFlow Sensor LFS-20-Z (0 - 20 lpm, Z-shape)) **LeviFlow Sensor LFS-20-U** (U-shape)	**100-30308** **100-30309**	
LeviFlow Sensor LFS-50-Z (0 - 50 lpm, Z-shape) **LeviFlow Sensor LFS-50-U** (U-shape)	**100-30310** **100-30311**	
LeviFlow Sensor LFS-80-Z (0 - 80 lpm, Z-shape) **LeviFlow Sensor LFS-80-U** (U-shape)	**100-30312** **100-30313**	
LeviFlow Concerter LFC-1C (24VDC, Single Channel, 2 Digital Outputs, 1 Digital Input, 1 Analog Output, RS485)	**100-30314**	
LeviFlow Concerter LFC-1C-F4 (for LFS-008) (24VDC, Single Channel, 2 Digital Outputs, 1 Digital Input, 1 Analog Output, RS485)	**100-30325**	
LeviFlow Concerter LFC-6C (24VDC, 6-Channel, RS485)	**100-30315**	
LeviFlow USB-RS485-WE-5000-BT (RS485 to USB Adaptor with cable)	**100-30334**	*Replaces EX-1303*
LeviFlow EX-1303 (USB-RS485/RS422 Adaptor)	**100-30318**	*This Adaptor version will not be delivered anymore by Levitronix as soon as stock is empty. Replacement by article# 100-30334.*
LeviFlow RS485 Cable (D-SUB Connector with Open-End Cable, for EX-1303 only)	**100-30319**	